




# » Quick Reference Sheet «

## SYMKLOUD Series MSU8700 Uplinks



### J1 & J2 SFP+ 10GB Connector

1 GND	11 GND
2 FAULT	12 RX-
3 DIS	13 RX+
4 SDA	14 GND
5 SCL	15 V_3V3
6 PRES#	16 V_3V3
7 SEL0	17 GND
8 LOS	18 TX+
9 SEL1	19 TX-
10 GND	20 GND



### LEDs Behavior

#### SFP LEDs (J1 & J2)

##### Link / Act# (Green)

Solid On (100% on): Link established

Blink: Activity

Solid Off (0% on): No link and no activity

##### Fault (Amber)

Solid On (100% on): Fault

Solid Off (0% on): No Fault, normal condition

#### Power (Green)

Solid On

100% on

Hub is ON, connected to shelf Manager

Blink

50% on

Hub is OFF (Only Management is powered).

Solid Off

0% on

Hub is OFF (Only Management is powered)

#### ID (Blue)

Solid On

100% on

Only management power present (No payload)

Blink


50% on

Indicate command is active

Solid Off

0% on

Node is ON or in standby mode (Payload present)



### Support

E-Mail : [support@ca.kontron.com](mailto:support@ca.kontron.com)

Tel : (800) 354-4223